



# **POSI** Base Fix With Steel Fixing Plate INSTALLATION GUIDE

## **Parts Included**

Steel plate x 15  
M12 bolts x 15  
M12 Washer x 15

## **Tools Required**

Drill  
13mm Diameter HSS Drill Bit  
4mm Diameter HSS Drill Bit  
Hammer  
Punch  
19mm Hex Socket  
Wrench  
Tape Measure  
Pencil

## **Safety**

Please wear eye protection  
and ear protection

Should any problems arise or you have any questions please don't hesitate to contact us:

T: +44 (0)1208 261 040

F: +44 (0)1208 261 041

E:- [sales@pure-vista.com](mailto:sales@pure-vista.com)

[www.pure-vista.com](http://www.pure-vista.com)



# POSI Base Fix With Steel Fixing Plate

## INSTALLATION GUIDE

1.



### DRILL THE HOLES

Use the POSIglaze channel to mark the position of the main fixing holes, then drill the holes to 13mm. Next, use the fixing plates to mark the 4 fixing holes. Drill all the pilot holes to 4mm before moving on.

2.



### PLACE THE FIXING PLATE

Attach the Steel Plates by screwing in the supplied self-drilling screws.

3.



### FIT THE CHANNEL

Place the POSI base channel back into position, on top of the Steel Plates. Ensure all the bolt holes line up correctly before proceeding to fix the channel with M12 bolts and washers. Continue with the POSI and glass installation as normal.

Should any problems arise or you have any questions please don't hesitate to contact us:

T: +44 (0)1208 261 040

F: +44 (0)1208 261 041

E: [sales@pure-vista.com](mailto:sales@pure-vista.com)

[www.pure-vista.com](http://www.pure-vista.com)